


BESTEK



MRS203BU

BESTEK

BESTEK GLOBAL LLC
1290E ELM ST, #A-8, ONTAIRO,
CA91761
COMPANY: BESTEK
PHONE: 909-816-0181


BESTEK GLOBAL LTD
Access House, 141 Morden Road
Mitcham
London CR4 4DG
United Kingdom
TEL: 02086481668

BESTEK 3 way Cigarette Lighter Splitter with 4-Port USB

Model: MRS203BU


Thank you for purchasing our products!
Please comply with this instruction manual strictly before using and keep it for future reference.

Product Introduction




How to Use


- a. Plug the Cigarette Lighter Splitter into the vehicle's cigarette lighter socket, switch on the power and LED indicator will lit.



- b. Convert and split your single car cigarette lighter to 3 sockets as well as 4 USB ports, which allows you to charge up to 7 devices simultaneously



- c. Only the socket on the left can light cigarettes.



Technical Specifications

Applicable Vehicles	12-24V All models
Total output power of 3 way cigarette lighter sockets	12V/120W, 24V/240W
USB output power	4*USB 5V/0-2.4A(Total: 21W)
Built-in Protection	Input over-voltage protection, output overload protection, short circuit protection, surge protection, over-current protection, under-voltage protection
Operating temperature	-5 C ~ 40 C
voltage warning	YES
battery voltage monitoring	YES, real-time display on the LED screen
Dimension	141.0mmx59.7mmx38.9mm
Weight	270±10g

LED display and troubleshooting

LED indicator on both USB ports and cigarette lighter sockets are not lit	Make sure the cigarette lighter is properly plugged into the socket
LED indicator on both USB ports and cigarette lighter sockets are not lit	Make sure the power button is switched on
LED indicator on both USB ports and cigarette lighter sockets are not lit	Check if the fuse is burned out
USB indicator is NOT lit, while cigarette lighter socket indicator is lit, LED screen displayed	It shows low battery voltage on the LED screen, and you need to contact the customer service for vehicle inspection
Blue USB indicator and Green cigarette lighter socket indicator are constantly lit	Normal working condition
USB indicator blinking	Too many devices are plugged into the cigarette lighter and you need to unplug some of them, then the LED indicator will back to normal working condition

Cautions

- Please make sure that the total output power of rest sockets is less than 60W while using the cigarette lighter socket to light cigarettes.
- Keep the unit away from direct sunlight.
- Do not hit against the product.
- Do not repair or disassemble the product without professional guidance.
- When the car battery voltage is less than 11.6V, please contact your car customer service for inspection to avoid of non-ignition.
- please make sure other lighter socket empty when use car lighe cigaretees funtion.

Car model: 12V		Car model: 24V		
11.6V ↓ ⊗	14.8V	23.2V ↓ ⊗	27.2V	Normal voltage after starting the car
	14.2V		26.6V	
	13.8V		26.0V	
	13.4V		25.4V	
	12.8V		24.8V	Normal battery voltage when the car is not started
	12.4V		24.2V	
	12.0V		23.8V	
Less than 11.6V	Less than 23.2V	Please contact your car customer service when the voltage such low		

Frequently asked questions

- Does my car model compatible with the cigarette lighter splitter?
It is compatible with all 12-24V car models , including cars, trucks and caravans etc.
- Which products can be charged?
Which including e-dog, car vacuum cleaner, heating cup, car recorder, car refrigerator, charge pump, navigator , MP3,MP4, PSP,mobile phone and tablet etc.
- What about safety performance? Can you switch off the power output thoroughly?
It comes with a 10A Fuse and Smart IC , with overload protection, over-voltage protection and over-current protection to protect your devices completely while charging. You can switch off all the power with one button.

D. What is the function of battery voltage monitoring?

You can monitor your car battery voltage easily, when batteryvoltage is less than 11.6V, the voltage display will blink to remind you of checking the vehicle battery. If the voltage is too high, the engine will beunsteady and the speaker will not work; If the voltage is too low, it willcause problem to car ignition and the light is not bright enough.

E. Why do we need LED indicator on the socket?

The cigarette lighter sockets come with soft green LED indicator, in this case, you will know whether the unit is working properly with a romantic atmosphere was being created.

F. Does the product durable?

The fireproof V0-grade PC Material was being used, it is heat-resistant and strong enough.

G. What to do when the fuse was blew up?

We have modified the fuse design from built-in to external for easy replacement, also it comes with a spare fuse to save your life.

Warranty

Our company provides customers with 18 Months warranty from the date of purchase.

Contact Us

For any inquiry or comment concerning our products, please send an email to:

[UK: cs@bestekcorp.com](mailto:cs@bestekcorp.com)

[US: customers@bestekcorp.com](mailto:customers@bestekcorp.com)

and we will respond to you as soon as possible.

If there is any quality-related issue with the product you may request a REPLACEMENT OR REFUND by submitting a request at our Amazon store.